

Instructions

Place the firmware updater executable in a folder of your choice. All firmware files you want to use need to be in the same folder. You can start the updater just by double clicking on the executable. In order to work the PUC2 Windows driver must be installed. Depending on the device which is connected you can only apply the appropriate firmware to the connected device. The first digit of the firmware versions explains which kind of device (aka. hardware revision) is addressed

- **versions 1.xx** are for standard PUC2 and PUC2 MIC based on hardware revision 1.x.
- **versions 2.xx** are for standard PUC2 based on hardware revision 2.x
- **versions 3.xx** are for PUC2 MIC LEA based on hardware revision 2.x

Changes

version 2.9.96.6

This version is able to process PUC2 firmware image files (*.bin) which contain PUC2 revision 2 images only aka. 'Single Revision' images.

version 2.9.87.8

This version locks against the ControlApp to gain exclusive access to the PUC2 device. That way you can only have one of both applications open at the same time. (ControlApp version \geq 3.0.14 needed) This version needs administrative user rights to get started.

version 2.9.86.25

This version will update now also the PUC2 MIC LEA. You have to place all your update firmware files in the same directory as the updater.

Your YELLOWTEC Team