



Quick Guide: iXm Presets

Download the current version of iXm and iXm Podcaster firmware including the presets here:

www.yellowtec.com/ixm/downloads

Available iXm Presets:

- The new firmware release version 2.2.4 provides new **iXm presets** that can be selected via the iXm Admin software and directly on the device. The presets allow iXm Recording Mic and iXm Podcaster to further adapt the iXm to recording environments for optimal voice recording results.

Preset 1 - FactoryNormal - LEA active, adapted for normal environments

Preset 2 - FactoryLoud - LEA active, adapted for loud environments

Preset 3 - FactoryNormalPreroll - based on Preset 1 + PreRoll Buffer

Preset 4 - FactoryNormalVAR - based on Preset 1 + PreRoll Buffer + Voice Activated Recording


Preset 5 - FactoryLEAOff - based on Preset 1, LEA is deactivated

Preset 6 - 9 all exactly via Preset 1 / Normal, memory locations for created, personal presets

How to load the Presets to your device:

- Start your iXm Recording Mic / iXm Podcaster by pressing the Stop button on the Playback Keypad and the Record Button on the Front Panel.
- Press Stop and FFW on the Playback Keypad to enter Admin Mode.
- Connect your iXm device to your PC or Mac via USB cable.
- Open the iXm Admin Software.
- Connect your iXm device to the software by entering the username and password.
E.g. the default admin account is username: admin, password: qwe123asd

- Click > File > Load settings from computer and choose the downloaded file named „iXm_default_settings_fw_2.2.4.iXm“



- Choose the Active Preset you want the device to run on



- Click > File > Send settings to device



- Confirm with “YES“ to overwrite the settings and you are done



How to choose and activate a Preset directly on your device:

- Start your iXm Recording Mic / iXm Podcaster by pressing the Stop button on the Playback Keypad and the Record Button on the Front Panel.
- Press Stop and FFW on the Playback Keypad to enter Admin Mode.
- You can now step through the available Preset by Playback Fast Forward and Playback Fast Rewind. If voice messaging is activated the iXm indicates the index number of the selected Preset by a message on the Headphones Out.
- To activate the currently selected Preset press Playback Play. Once again a voice message will follow if activated.
Now you are done, the iXm will leave the Admin Mode automatically and runs on the activated Preset.